


## Fastener Tightening Specifications


Application	Specification	
	Metric	English
Data Link Connector Screw	2.5 N·m	22 lb in

## Data Link Connector Replacement




Callout	Component Name
<b>Preliminary Procedure</b>	
Remove the left side instrument panel insulator panel. Refer to <a href="#">Instrument Panel Insulator Panel Replacement - Left Side</a> .	
1	Data Link Connector Screw (Qty: 2)  <b>Caution:</b> Refer to <a href="#">Fastener Caution</a> in the Preface section.  <b>Tighten</b> 2.5 N·m (22 lb in)
2	Data Link Connector

## Body Control Module Replacement



Callout	Component Name
<p><b>Preliminary Procedure</b></p>	
<p>Remove the left side instrument panel insulator panel. Refer to <a href="#">Instrument Panel Insulator Panel Replacement - Left Side</a> .</p>	
<p>1</p>	<p>Body Control Module</p> <p><b>Procedure</b></p> <ol style="list-style-type: none"> <li>1. Disconnect the electrical connectors.</li> <li>2. Reprogram the module if replaced. Refer to <a href="#">Control Module References</a> .</li> </ol> <p><b>Tip</b>                      Push tab to release the body control module from the bracket.</p>

## Rear Body Control Module Replacement



Callout	Component Name
<p><b>Preliminary Procedures</b></p> <p>Remove the left rear quarter lower trim panel. Refer to <a href="#">Quarter Lower Rear Trim Panel Replacement</a>.</p>	
<p>1</p>	<p>Rear Body Control Module Assembly</p> <p><b>Procedure</b></p> <ol style="list-style-type: none"> <li>1. Disconnect the electrical connectors.</li> <li>2. Reprogram the rear body control module if replaced. Refer to <a href="#">Control Module References</a>.</li> </ol> <p><b>Tip</b>                      Push in the tab to release the module from the liftgate actuator assembly.</p>